

SPECIFICATION

Working Voltage: AAA battery X 2 PCS(2.2-3V)

Carrier Frequency: 38KHz $\pm$ 2KHZ

Operation Distance Max. 15M/49ft(3V)

Emission Angle: <30 degree

Standby Current: <1.2uA

Working Current: <5mA

Peak Current: <30mA

Working Temp: -20°C-60°C

Storage Temp: -30°C-85°C



WARNING

Remove the batteries from compartment if the remote will not be used in 30 days.

OVERVIEW

The remote control Wireless IR configuration tool is a handheld tool for remote configuration of IR-enabled fixture integrated sensors. The tool enables device to modify via pushbutton without ladders or tools.

The remote control send sensor setting at mounting height up to 50 feet.



Detection Area +:

Adjust the sensitivity of the sensor to increase the detection range

Detection Area -:

Adjust the sensitivity of the sensor to reduce the sensing range

Restore Defaults:

Restore the sensitivity of the sensor to its original state

Reset Bluetooth:

Reset the Bluetooth sensor

ORDERING INFORMATION

RC-103

Sensor commissioning and control remote